单机版安装

一、硬件/系统要求

推荐硬件需求:

- ♣ 4 GB 以上系统内存(RAM)
- 👃 5 GB 可用磁盘空间
- 🜲 🛛 2 mpb 或更高的互联网连接,用于软件激活,产品更新和在线服务,如 Pack Installer

支持操作系统: 支持 64 位版本的 Microsoft Windows:

- Windows 11 Home
- Windows 11 Pro
- Windows 11 Enterprise
- Windows 11 Education
- Windows 10 Home
- Windows 10 Pro
- ♣ Windows 10 Enterprise
- Windows 10 Education
- Windows 8.1
- Windows 8.1 Pro
- ♣ Windows 8.1 Enterprise

二、软件下载

MDK 客户端 (5.38 版本) 下载链接:

MDK 客户端下载链接:

链接: https://pan.baidu.com/s/1dcuGMHqFvVhChdEguvLkXQ?pwd=snrw

提取码: snrw

三、软件安装

1. 运行安装软件安装包, 打开安装向导

	Setup MDK-ARM V5.37	×
	Welcome to Keil MDK-ARM Release 4/2022	arm KEIL
	This SETUP program installs:	
	MDK-ARM V5.37 This SETUP program may be used to update a previous product in However, you should make a backup copy before proceeding.	istallation.
	It is recommended that you exit all Windows programs before cont Follow the instructions to complete the product installation.	inuing with SETUP.
	- Keil MDK-ARM Setup	Back Next >> Cancel
	图 3-1 安装向	司导
2. 勾选同意	穒 License 协议	
	Setup MDK-ARM V5.37	×
	License Agreement Please read the following license agreement carefully.	arm KEIL



图 3-2 license 协议

3. 选择安装路径

Folder Selection	
Select the folder where SETUP will install files.	armkeil
Press 'Next' to install MDK-ARM to these folders. Press 'Brow	vse' to select different folders for installation.
Destination Folders	
Core: D:\Keil_MDK537	Browse
Pack: D:\Keil_MDK537\Arm\Packs	Browse
IN THE REPORT OF	

图 3-3 路径更改



4. 填写用户信息

Setup MDK-ARM	V5.37		
Customer Information Please enter your information.		arm KEIL	
Please enter your	name, the name of the company	for whom you work and your E-mail address.	
First Name:	First Name		
Last Name:	Last Name		
Last Name: Company Name:	Last Name Emdoor		
Last Name: Company Name: E-mail: - Keil MDK-ARM Setu	Last Name Emdoor (:@emdoor.com	以收到邮件的邮箱	

图 3-4 填写用户信息

接下来按照提示点击 Next 直到完成安装

四、获取 CID

1. MDK 软件单机版机版 License 授权,选中 MDK 图标,运行程序。 2. 在 File 菜单中可以找到 license 管理选项,如下图:

File	Edit View Project	Flash D	ebug Peripherals Tools SVCS	Window
	New	Ctrl+N		霍 課 //
2	Open	Ctrl+O		• • 🚳
	Close			· · · ·
	Save	Ctrl+S	4 🖬	_] mai
	Save As			44
14	Sava All			45
	Save All			40
	Device Database			48
	License Management			49
			.c (LED)	50
	Print Setup			51
3	Print	Ctrl+P		52
	Print Preview		brary:PIO)	53

图 4-1 打开授权界面

3. 选择 License Management...弹出新的对话框如下图:

Name: Company:	mation First Name Last Name Emdoor	Computer ID CID: CJLEV-A5314 Get LIC via Internet
Email: Product MDK-ARM	⊴@emdoor.com Ucense ID Code (LIC)/Product variant 651. 1R2D	Support Period S Exp: n = 2032
		Auros I desser
	ib code (Lie).	The state of the s

图 4-2 授权界面

4. 上图中你可以看到一个 CID 号。